## Information for compliance with Commission Regulation 801/2013

Model Name: DCP-T420W,DCP-T425W

| Network Port | Power consumption | | Default Timer Values | |
|---|---|---|---|---|
| | Networked Standby mode | Off mode | To Networked Standby mode | To Off mode |
| USB | .7W | .2W | 5min | 120min |
| Wi-Fi | .9W | N/A | 5min | N/A |
| All network ports activated and connected | 1.0W | N/A | 5min | N/A |

**How to enable/disable Wireless LAN**

1 Press **WiFi** and (**Stop**) at the same time.
The **Power LED**, **Warming LED**, and **Ink LED** lit for a second, and then the **WiFi** starts blinking.

2 Press **Mono Start** to to set to On or Off.

- If Wi-Fi is enabled, the **Power LED** blinks once, and then the **Power LED** and **Wifi** are lit.
- If Wi-Fi is disabled, the **Power LED** blinks twice, and then the **Power LED** is lit.